

3.1.1 ERROR TABLE

ERROR CODE (bin)	TYPE	AFFECTED COMPONENT
1	Throttle fault	THROTTLE
2	Cruise fault	CRUISE BUTTON
4	Watchdog	ECU UNIT
8	DIAG	ECU UNIT
16	DIAG	ECU UNIT
32	DIAG	ECU UNIT
64	FPU fault	ECU UNIT
128	ALU fault	ECU UNIT
256	Flow fault	ECU UNIT
512	Echo fault	ECU UNIT
1024	Reverse check fault	REVERSE COMMAND
2048	Motor overload	MOTOR
4096	Motor overcurrent	MOTOR
8192	Battery overvoltage	BATTERY
16384	Motor temperature	MOTOR
32768	Hall sensor fault	MOTOR

Rev Nr	Description	Written by	Reviewed by	Authorized By	Effective date
00	Initial release	Riccardo Colomba	Antonio Benedini	Andrea Stella	2021-03-11